

7250A Series GC QTOF System Site Preparation Checklist

Thank you for purchasing an Agilent instrument. To get you started and to assure a successful and timely installation, please refer to this specification or set of requirements.

Correct site preparation is the key first step in ensuring that your instruments and software systems operate reliably over an extended lifetime. This document is an **information guide AND checklist** prepared for you that outlines the supplies, consumables, space and utility requirements for your equipment for your site.

For additional information about our solutions, please visit our web site at <http://www.chem.agilent.com/en-US/Pages/HomePage.aspx>

Customer Responsibilities

Make sure your site meets the following prior to the installation date using the checklist below. For details, see specific sections within this document, including:

- The necessary laboratory or bench space is available.
- The **environmental conditions for the lab** as well as laboratory gases, tubing.
- The **power requirements** related to the product (e.g. **number & location** of electrical outlets).
- The **required operating supplies** necessary for the product and installation.
- Please consult **Other/Special Requirements** section below for other product-specific information.
- For more details, please consult the product-specific Site Prep manual (delete this line if a Site Prep Guide does not exist).
- If Agilent is delivering installation and familiarization services, users of the instrument should be present throughout these services; otherwise, they will miss important operational, maintenance and safety information.

Important Customer Information


1. If you have questions or problems in providing anything described as a *Customer Responsibilities* above, please contact your local Agilent or partner support/service organization for assistance prior to delivery. In addition, Agilent and /or its partners reserve the right to reschedule the installation dependent upon the readiness of your laboratory.
2. Should your site not be ready for whatever reasons, please contact Agilent as soon as possible to re-arrange any services that have been purchased.
3. Other optional services such as additional training, operational qualification (OQ) and consultation for user-specific applications may also be provided at the time of installation when ordered with the system, but should be contracted separately.

**7250A Series GC QTOF System
Site Preparation Checklist**

7250A Series GC QTOF System



7250A Series GC QTOF System Site Preparation Checklist



Dimensions and Weight

Identify the laboratory bench space before your system arrives based on the table below.

Pay special attention to the total height and total weight requirements for all system components you have ordered and avoid bench space with overhanging shelves. Also pay special attention to the total weight of the modules you have ordered to ensure your laboratory bench can support this weight.

Special Notes:

1. This does not include the automated sampling devices which could be used on the system.
2. Please note: the length of the vacuum hose is 130 cm or about 4.24 feet from the high vacuum pump to the foreline pump, while the length of the foreline pump power cord is 2 M or about 6.6 feet.
3. A table must be large enough to support the mainframe and the size of the base plus additional accessories.
4. The dimensions and weight of the instrument needs to be placed on a laboratory bench that is at least 101 cm (40 in) deep. The instrument requires a space of at least 40.0 cm (16 in) on both sides, and approximately 30 cm (~ 12 in) at the rear for the circulation of air, vacuum pump hose, and room for electrical connections.
5. If the bench is to support a complete Agilent Technologies 7250A Series GCMS QTOF system make sure that the bench is designed to carry the total weight of all the components.
6. Note the overall height of the QTOF is about 189 cm (74.5 in) with bench tables on average around 78.7 cm (31 in) tall which means 189 cm (QTOF) + 79 cm (Table) +30 cm (clearance) = 298 cm would be the minimum for room height; 298 cm-2.98 m-117 in-9.76 feet.

DESCRIPTION	Weight		Height		Depth		Width	
	kg	lbs	cm	in	cm	in	cm	in
GC-QTOF	152	335	189	74.5	100	39.5	88	34.5
DS202 – Foreline Pump - Wet	25	55	26.7	10.5	43.0	16.9	15.8	6.22
IDP-15 – Foreline Pump - Dry	45	100	36.4	14.3	48.5	19.1	33.3	13.1
Please refer to the GC Site Preparation Checklist ALS Site Preparation Checklist								
Workstation PC system (monitor, CPU, printer)	50	112	54	21.3	54	21.3	54	21.3

**7250A Series GC QTOF System
Site Preparation Checklist**



Environmental Conditions

Operating your instrument within the recommended temperature ranges insures optimum instrument performance and lifetime.

Special Notes:

1. Performance can be affected by sources of heat & cold e.g. direct sunlight, heating/cooling from air conditioning outlets, drafts and/or vibrations.
2. The site's ambient temperature conditions must be stable for optimum performance of the system's modules as specified in the "Environmental Specifications" section of the Site Preparation Manual. Temperature changes should not exceed 3°C from its intended set-point to achieve best possible baseline stability. Higher variations will result in higher signal drift and wander of the baseline.
3. The bench or supporting surface must be vibration free.
4. The following table may help you calculate the additional BTUs of heat dissipation from this new equipment. Maximums represent the heat given off when heated zones are set for maximum temperatures.

Instrument Description	Operating temp range °C	Operating humidity range (%)	Heat Dissipation (BTU)
7250A Series GC/MS	15 to 35 °C	20% - 80%	6200 BTU / hour including GC/MS interface
Please refer to the GC Site Preparation Checklist ALS Site Preparation Checklist			



Exhaust Venting Requirements

The 7250A Series GC/MS System foreline pump exhaust is recommended to be vented outside of the laboratory environment. Exhaust vent system should not be part of an environmental control system that recirculates air inside of a building. Exhaust venting requirements need to comply with all local environmental and safety codes. If the exhaust is non-toxic then an oil mist filter should be used on the foreline pump exhaust.

1. A 6-meter (20ft.) length (cut to length for the location of the instrument) of 1/2 in id PVC/vinyl tubing is recommended for venting the foreline pump exhaust. This is sufficient for two 3-meter (10-foot lengths).
2. The foreline pump exhaust should not be shared with exhaust tubing from another instrument. Separate 1/2 inch hose barbs are required to connect the tubing to the exhaust vent.

**7250A Series GC QTOF System
Site Preparation Checklist**

Power Consumption
Special Notes:

1. If a computer system is supplied with your instrument, be sure to account for those electrical outlets.

Instrument Description	Line Voltage & Frequency (V, Hz)	Maximum Power Consumption (VA)
7250A Series GC QTOF	200-240VAC (-10% / + 5%) 50/60 Hz ± 5%	1800VA (1200VA for foreline pump only)
Please refer to the GC Site Preparation Checklist ALS Site Preparation Checklist		
Workstation PC system (monitor, CPU, printer)	120VAC (-10% / + 5%), 50/60 Hz ± 5%	1000VA
	200-240VAC (-10% / + 5%), 50/60 Hz ± 5%	1000VA

Part Number	Line Voltage Power Cords
8120-6360	Power Cord, Taiwan/S America, C19, 20A
8120-6903	Power Cord, Japan, C19, 20 amp
8120-8619	Power Cord, Australia, C19, 16 amp
8120-8620	Power Cord, GB/HK/SG/MY, C19, 13 amp
8120-8622	Power Cord, Swiss/DK, C19, 16 amp
8121-0070	Power Cord, China, C19, 15 amp, Fast
8121-0161	Power Cord, Israel, C19, 16 Amp
8121-0675	Power Cord, Argentina, C19, 16 amp
8121-0710	Power Cord, India/S.Africa, C19, 15 Amp
8121-1222	Power Cord, Europe+S Korea, C19, 15A, 250V
8121-1301	Power Cord, Thai 220V, 15 A, 1.8M, C19
8121-1787	Power Cord, Brazil, C19, 250V Max
8121-0075	Power Cord, US 240V, C19, 15 amp

**7250A Series GC QTOF System
Site Preparation Checklist**

Required Operating Supplies by Customer
Special Notes:

1. For information on Agilent consumables, accessories and laboratory operating supplies, please visit <http://www.chem.agilent.com/en-US/Products/consumables/Pages/default.aspx>

Item Description, (including dimensions etc)	Vendor/Part Number (if applicable)	Recommended Quantity
Analytical Table	www.onepointesolutions.com	1
H-31" D-40" W-96"	www.ChemTops.com	
Noise Chamber for foreline pumps, coasters		
Computer Table (if table is same depth then they can be placed next to each other)	www.onepointesolutions.com	1
H-31" D-40" W-36"	www.ChemTops.com	
Monitor support rack and Keyboard rack, coasters		
Table is just large enough to hold GC QTOF and GC.	Mass Spec Bench, G3215A	2


Other/Special Requirements

Gases are supplied by tanks, internal distribution system, or gas generators. Tank supplies require two staged, pressure regulation.

To connect tubing to the supply, it must have one 1/8-inch Swagelok female connector for each gas. Make sure that your regulator has the appropriate sized adapter to end with a 1/8-inch Swagelok female connector. (The URL of Swagelok's web site is <http://www.swagelok.com> to help assist is finding connectors.)

Please refer to the GC Site Preparation Guide and the ALS Site Preparation Guide for gas requirements for those products.

7250A Series GC QTOF System Site Preparation Checklist

7250A Series Gas Flow Limitations

Feature	7250A Series
High Vacuum Pump Type 1	Split-Flow Turbo
High Vacuum Pump Type 2	Turbo
High Vacuum Pump Type 3	Turbo
Carrier Gas Optimal gas flow ml/min (a)	1.0 – 1.5
Carrier Gas Max recommended gas flow, ml/min	2.0
Carrier Gas Max gas flow, ml/min (b)	2.4
Collision Cell Gas Flow Rate (Nitrogen/Helium – via CC EPC module)	5 ml/min
Nitrogen Purging (Nitrogen – minimum 80 psi)	Up to 10 l/min
Electronics Cooling	2-3 l/min
Venting Flight Tube	2-3 l/min
Fast Vent Purge	2-3 l/min
Max column id	0.32mm (30m)

a Total gas flow into the MS: column flow plus reagent gas flow (if applicable)

b Expect degradation of spectral performance and sensitivity

1. Purity specification given is the minimum acceptable purity. Major contaminants can be water, oxygen, or air.
2. Pre-cleaned 1/8" copper tubing and 1/8-in Swagelok® fittings are supplied as part of the ship kit to connect the collision cell gas to the collision cell inlet fitting.
3. Never use liquid thread sealer to connect fittings.

7250A Series Carrier and Reagent Gases

Carrier and reagent gas requirements	Typical pressure range (psi)	Typical flow (ml/min)
Helium (required)	50 to 80	20 to 100 (column and split flow)
Hydrogen	Not supported	Not supported

7250A Series GC QTOF System Site Preparation Checklist



Gas Selection

Agilent recommends that carrier and detector gases be 99.9995% pure. Air needs to be zero grade or better. Agilent also recommends using traps to remove hydrocarbons, water, and oxygen.

7250A Series Carrier and Reagent Gases Purity.

Carrier and reagent gas requirements	Purity	Note
Helium (Carrier)	99.9995%	hydrocarbon free
Nitrogen (Mainframe)	99.999%	Research or SFC grade

For both the GC and MS it is recommend two (2) step regulators be used with 1/8" size outlets.




Remote Diagnostics

Easy access to diagnostic information and to the system operator helps our service engineers diagnose problems or share information. We recommend these features to help support your new system:

1. A LAN connection for the Data Acquisition and Data Analysis PC is recommended to provide remote diagnostics capability for the 7250A Series GC/MS System.
2. A phone line close to the instrument is strongly recommended for communication with the system operator.

7250A Series GC QTOF System Site Preparation Checklist



Other considerations

Basic Tools

Your GC-QTOF comes with a few basic tools and consumables depending on the specific inlet and detector that you ordered. Here is a general list which one will get with the instruments or should have on-hand.

Tool or consumable	Used for
Inlet wrench	Replacing inlet septa and liners.
T10 and T20 Torx wrenches	Remove tray. Remove covers to access EPC modules, traps, and possible leaks.
Column cutter	Column installation.
1/8-inch Tee, Swagelok, brass	Connect gas supplies
1/8-inch nuts & ferrules, Swagelok, brass	Connect gas supplies
1.5 mm and 2.0 mm hex driver	Source maintenance (disassembly)
Tool bag	Used to hold GC and MS tools
Q-Tips	Used to clean source parts
Cloths	Used to keep surfaces clean and parts clean
Gloves	Used to reduce contamination on parts GC and MS

MS Maintenance supplies	
Description	Part number
Abrasive paper, 30 µm	5061-5896
Alumina powder	393706201
Cloths, clean (package of 300)	05980-60051
Cloths, cleaning (package of 300)	9310-4828
Cotton swabs (package of 100)	5080-5400
Foreline pump oil, Inland 45	6040-0834
Gloves, clean, large	8650-0030
Gloves, clean, small	8650-0029
Grease, Apiezon L, high vacuum	6040-0289
IDP-15 Tip Seal Maintenance Kit (Tip Seal, Cloth, Scouring Pad, Swab, Gloves, Filter)	5190-9613
Ferrules	
Blank, graphite-vespel	5181-3308
GC/MS interface	
0.3-mm id, 85% Vespel 15% graphite, for 0.10-mm id columns	5062-3507
0.4-mm id, 85% Vespel 15% graphite, for 0.20-mm id and 0.25-mm id columns	5062-3508
0.5-mm id, 85% Vespel 15% graphite, for 0.32-mm id columns	5062-3506



7250A Series GC QTOF System Site Preparation Checklist

Miscellaneous parts and samples	
Filament assembly, EI	G3850-60021
Octafluoronaphthalene (OFN), 1 pg/ul	5188-5348
Octafluoronaphthalene (OFN), 100 fg/ul	5188-5347
Perfluorotributylamine (PFTBA) sample kit	05971-60571
Sample, evaluation, hydrocarbons	05970-60045

Important Customer Web Links

For additional information about our solutions, please visit our web site <http://www.chem.agilent.com/en-US/Pages/HomePage.aspx>

Need to get information on your product? Literature Library -

<http://www.agilent.com/chem/library>

Need to know more? Customer Education –

<http://www.agilent.com/chem/education>

Need technical support, FAQs? –

<http://www.agilent.com/chem/techsupp>

Need supplies? –

<http://www.agilent.com/chem/supplies>